

SPECIFICATION NO: NW307t

NEW WORK/REPAINT: NEW WORK – EXTERIOR

SUBSTRATE: Metals - Galvanized Iron

PAINT FINISH: Plascon Nuroof Cool PRODUCT CODE: TRP 200

(Smooth finish - water based, premium quality

acrylic roof paint)

COLOUR: Standard colours per colour card.

ENVIRONMENT: The Maintenance Cycle is a guide but can vary due to micro-climate changes identified on

the site which will affect the longevity of the coating system

As per ISO 12944-2:1998 Maintenance Cycle (Years)

 C1 Inland
 7

 C3 Industrial
 7

 C5 Coastal / Marine
 7

Plascon Coating	Application	Spreading	WFT/DFT	Reducer/	Overcoating	Technical	TVOC
System	Method	Rate	μm	Cleaner	time	Data Sheet	g/£
		m²/ℓ	(min & max)		h @ 23 ℃	No	
Primer	B, R or S	@ 55 μm	WFT 135-	Water	WB topcoat:	EMS 18	53.5
Plascon Plascosafe		Theo: 6.7	162		8		
18 Primer		Prac: 4.4	DFT 50-60		SB topcoat:		
(EMS 18)					16		
1 st Finishing Coat	B, R or S	@ 42.5 μm	WFT 100-140	Water	2	TRP 200	40
Plascon Nuroof		Theo: 8.5	DFT 35-50				
Cool Acrylic Roof		Prac: 5					
Paint							
(TRP 200)							
2 nd Finishing Coat	B, R or S	@ 42.5 μm	WFT 100-140	Water	2	TRP 200	40
Plascon Nuroof		Theo: 8.5	DFT 35-50				
Cool Acrylic Roof		Prac: 5					
Paint							
(TRP 200)							



Revision Date: June 2016



SPECIFICATION NO: NW307t

SURFACE PREPARATION:

Galvanized iron in good condition:

- Apply Plascon Galvanized Iron Cleaner (GIC 1) to all bare Galvanized areas by brush, broom or spray.
- Allow to react for 1 minute. Rinse off with tap water using bristle brooms or brushes or Scotch Brite pads to remove all surface contaminants.
- ^ Check if surface is water break-free. If not, repeat process. Allow to dry completely.

Old Galvanized iron partially rusted:

- Apply Plascon Galvanized Iron Cleaner (GIC 1) to all bare Galvanized areas by brush, broom or spray.
- ^ Allow to react for 1 minute. Rinse off with tap water using bristle brooms or brushes or Scotch Brite pads to remove all surface contaminants.
- ^ Check if surface is water break-free. If not, repeat process. Allow to dry completely.
- Mechanically wire brush or hand sand rust areas to bright metal. Remove dust.
- ^ Spot prime areas where rust has been removed with Plascon Plascotuff 3000 Series (PEX 3004 Grey/PEH 3 Hardener) Allow 16 hours to dry.

APPLICATION:

Primer Coat

^ Prime the entire surface with Plascon Plascosafe 18 Primer (EMS 18) to achieve a continuous film. Allow 8 hours drying time (water based topcoat) or 16 hours drying time (solvent based topcoat).

Finishing Coats

Apply two full coats of Plascon Nuroof Cool Acrylic Roof Paint (TRP 200) to achieve complete obliteration, allowing 2 hours drying between coats.

TABLE REFERENCES:

- Technical Data Sheet (TDS): User must always ensure that latest issue is used.
- A B = Brush (ready for use), R = Roller (synthetic, min. 10mm pile) (ready for use), S = Airless spray (ready for use).
- ^ Theoretical spreading rate quoted is for smooth non-porous substrates and does not include allowance for surface profile, porosity, wastage and uneven film application. Suitable allowance should be made according to type of work, method and skill of applicator. Practical spreading rate quoted is an average guide only actual must be determined by user.
- Overcoating times are at 23 °C and 75 % relative humidity. Longer times must be allowed under cooler and moist conditions. DO NOT paint during inclement weather and when temperature is below 10 °C.
- ^ Fading and chalking will occur to a greater or lesser degree depending on pigmentation and generic binder type.
- ^ NB: Life expectancy may vary, depending on environmental conditions and stresses, within the macro/micro climate of the project.

Copyright @Kansai Plascon (Pty) Ltd 2013. All rights reserved. No part of this work may in any form or by any means be reproduced without prior written permission of the copyright owner. PLASCON is the registered trade mark of Kansai Plascon (Pty) Ltd,



Revision Date: June 2016