

NEW WORK/REPAINT: NEW WORK – INTERIOR

SUBSTRATE: Gypsum Plaster (Rhinolite, Rhinoglide, Creststone, Putty Plaster)

PAINT FINISH: Plascon Waterbased Velvagio PRODUCT CODE: **VLW**
Premium Quality Satin Finish Non Drip Waterbased Enamel

COLOUR: White and standard colours as per colour card, plus Plascon colour system and other fan decks.

ENVIRONMENT: **The Maintenance Cycle is a guide but can vary due to micro climate changes identified on the site which will affect the longevity of the coating system**

As per ISO 12944-2:1998 Maintenance Cycle (Years)

C1 -	Inland	10
C3 -	Industrial	10
C5 -	Coastal / Marine	10

Plascon Coating System	Application Method	Spreading Rate m ² /ℓ	WFT/DFT μm (min & max)	Reducer/ Cleaner	Overcoating time h @ 23 °C	Technical Data Sheet No	TVOC g/ℓ
Primer: Plascon Plaster Primer (UC 56)	B, R or S	@ 40 μm Theo: 8.8 Prac: 5.1	WFT 100-129 DFT 35-45	Min. Turps (AZH I)	16	UC 56	423
1st Finishing Coat Plascon Waterbased Velvagio (VLW/TVW)	B, R or S	@ 35 μm Theo: 9.7 Prac: 5.5	WFT 88-118 DFT 30-40	Water	4	VLW	46-50 white, pastel tinted < 53-60 deep & transparent bases tinted
2nd Finishing Coat Plascon Waterbased Velvagio (VLW/TVW)	B, R or S	@ 35 μm Theo: 9.7 Prac: 5.5	WFT 88-118 DFT 30-40	Water	4	VLW	46-50 white, pastel tinted < 53-60 deep & transparent bases tinted

SURFACE PREPARATION:

- ^ Ensure surfaces are clean dry, sound and free from surface contaminants.
 - ^ Remove contaminants using a mutton cloth in-conjunction Mineral Turps (AZH 1)
 - ^ Soft undercured surfaces may be restored to a sound surface with Plascon Bonding Liquid (CVI 14) thinned 20% by volume with Mineral Turpentine (AZH 1). Allow 16 hours to dry, but not more than 48 hours, before painting.
 - ^ Make good defects using Polycell Polyfilla Interior (101002). Allow at least 30 minutes to dry and sand smooth with 220 grit paper and dust off.
 - ^ Where necessary the Gypsum may be skimmed using Terraco Handycoat EZ Skim (TER 1200) to make good trowel marks, defects and fine cracks. Allow 2 hours to dry and sand using 220 – 350 grit paper depending on the smooth profile required. Dust off.
-

APPLICATION:

Primer Coat

- ^ Apply one coat of Plascon Plaster Primer (UC 56) to achieve a continuous film. Allow 16 hours to dry.

Finishing Coats

- ^ Apply two full coats of Plascon Waterbased Velvaglo (VLW/TVW) to achieve complete obliteration, allowing 4 hours drying between coats.
NB: if white is used, three coats might be necessary to achieve obliteration.
-

TABLE REFERENCES:

- ^ Technical Data Sheet (TDS): User must always ensure that latest issue is used.
- ^ B = Brush (ready for use), R = Roller (synthetic, min. 10mm pile) (ready for use), S = Airless spray (ready for use).
- ^ Theoretical spreading rate quoted is for smooth non-porous substrates and does not include allowance for surface profile, porosity, wastage and uneven film application. Suitable allowance should be made according to type of work, method and skill of applicator. Practical spreading rate quoted is an average guide only - actual must be determined by user.
- ^ Overcoating times are at 23 °C and 75 % relative humidity. Longer times must be allowed under cooler and moist conditions. DO NOT paint during inclement weather and when temperature is below 10 °C.
- ^ Fading and chalking will occur to a greater or lesser degree depending on pigmentation and generic binder type.
- ^ NB: Life expectancy may vary, depending on environmental conditions and stresses, within the macro/micro climate of the project.

Copyright ©Kansai Plascon (Pty) Ltd 2013. All rights reserved. No part of this work may in any form or by any means be reproduced without prior written permission of the copyright owner. PLASCON is the registered trade mark of Kansai Plascon (Pty) Ltd,
