

SPECIFICATION NO: NW209t

NEW WORK/REPAINT:	NEW WORK – INTERIOR						
SUBSTRATE:	Gypsum Plaster (Rhinolite, Rhinoglide, Cretestone, Putty Plaster)						
PAINT FINISH:	Professional Super Matt PRODUCT CODE: PEM 900 (Smooth finish – water based, high cover, durable matt acrylic)						
COLOUR:	White plus Plascon colour system and other fan decks.						
ENVIRONMENT:	The Maintenance Cycle is a guide but can vary due to micro-climate changes identified on the site which will affect the longevity of the coating system						
	As per ISO 12944-2:1998	Maintenance Cycle (Years)					
	C1 - Inland C3 - Industrial C5 - Coastal / Marine	5 5 5					

Plascon Coating System	Application Method	Spreading Rate m²/ℓ	WFT/DFT μm (min & max)	Reducer/ Cleaner	Overcoating time h @ 23 °C	Technical Data Sheet No	TVOC g/୧
Primer Professional Gypsum and Plaster Primer (PP 700)	B, R or S	@ 40 μm Theo: 8.8 Prac: 5.1	WFT 109-129 DFT 35-45	Min. Turps (AZH I)	16	PP 700	423
1 st Finishing Coat Professional Super Matt (PEM 900/TSA)	B, R or S	@ 30 μm Theo: 11.3 Prac: 6.3	WFT 74-103 DFT 25-35	Water	1	PEM 900	<5 white & pastel tinted <16 deep & transparent
2 nd Finishing Coat Professional Super Matt (PEM 900/TSA)	B, R or S	@ 30 μm Theo: 11.3 Prac: 6.3	WFT 74-103 DFT 25-35	Water	1	PEM 900	<5 white & pastel tinted <16 deep & transparent





SPECIFICATION NO: NW209t

SURFACE PREPARATION:

- Ensure surfaces are clean dry, sound and free from surface contaminants.
- A Remove contaminants using a mutton cloth in-conjunction Mineral Turps (AZH 1)
- Soft undercured surfaces may be restored to a sound surface with Plascon Bonding Liquid (CVI 14) thinned 20 % by volume with Mineral Turpentine (AZH 1). Allow 16 hours to dry, but not more than 48 hours, before painting.
- Make good defects using Polycell Polyfilla Interior (101002). Allow at least 30 minutes to dry and sand smooth with 220 grit paper and dust off.
- Where necessary the Gypsum may be skimmed using Terraco Handycoat EZ Skim (TER 1200) to make good trowel marks, defects and fine cracks. Allow 2 hours to dry and sand using 220 – 350 grit paper depending on the smooth profile required. Dust off.

APPLICATION:

Primer Coat

 Apply one coat of Professional Gypsum and Plaster Primer (PP 700) to achieve a continuous film. Allow 16 hours to dry.

Finishing Coats

 Apply two full coats of Professional All Purpose Matt (PEM 900/TSA) to achieve complete obliteration, allowing 1 hour drying between coats.

TABLE REFERENCES:

- ^ Technical Data Sheet (TDS): User must always ensure that latest issue is used.
- A B = Brush (ready for use), R = Roller (synthetic, min. 10mm pile) (ready for use), S = Airless spray (ready for use).
- Theoretical spreading rate quoted is for smooth non-porous substrates and does not include allowance for surface profile, porosity, wastage and uneven film application. Suitable allowance should be made according to type of work, method and skill of applicator. Practical spreading rate quoted is an average guide only - actual must be determined by user.
- Overcoating times are at 23 °C and 75 % relative humidity. Longer times must be allowed under cooler and moist conditions. DO NOT paint during inclement weather and when temperature is below 10 °C.
- Fading and chalking will occur to a greater or lesser degree depending on pigmentation and generic binder type.
- NB: Life expectancy may vary, depending on environmental conditions and stresses, within the macro/micro climate of the project.

Copyright @Kansai Plascon (Pty) Ltd 2013. All rights reserved. No part of this work may in any form or by any means be reproduced without prior written permission of the copyright owner. PLASCON is the registered trade mark of Kansai Plascon (Pty) Ltd,

