

Cornicing



Roman

Royal Elizabeth

Colonial

Gothic

WHY DAS PRODUCTS ARE VALUE FOR YOUR MONEY

All DAS products are light-weight, making them easy to transport and install. No nails, hammers or drills are required to install DAS decorative products. Cornicing is supplied in lengths of 2m, allowing for easy planning, storage and installation. Cornicing for the average house weighs around 20 kgs. Ceiling Tiles for the average room weigh as little as 7 kgs, as well as being simple to install. Ceiling Roses are produced in 3 different patterns and sizes. Each Ceiling Rose allows for installation of a light fitting, which can add to the overall effect of a decorated room.

All DAS decorative products can be painted, using water based acrylic paints, immediately after installation. A PVA or water based primer would be necessary if a solvent based paint were to be used to finish. When working with DAS products, we recommend that the correct tools and adhesive are used for your project. DAS 2 in 1 Adhesive is a quality, all-purpose adhesive, made under strict quality controls, for use in conjunction with DAS products. Failure to use DAS 2 in 1 Adhesive may result in damage to your DAS products. DAS 2 in 1 Adhesive serves not only as an adhesive, but also as a filler. One cartridge of adhesive installs approximately 7m of Cornice or 3m² of Ceiling Tiles.

The DAS DIY kit contains all the tools required by decorating enthusiasts to make decorating simple and affordable. This includes a saw, mitre box and caulking gun and other necessary tools. The kit also contains a CD to assist with the selection and installation of your DAS decorative products.

DAS products last indefinitely under normal conditions as well as humid conditions and are not damaged by water in the case of leaks etc. DAS products are strong, durable and will not chip or break if dropped. Any damage to product is easily repairable using the DAS 2 in 1 Adhesive.


Cornicing Profiles




DAS 005
S005



DAS 010
Monroe



DAS 015
Classic



DAS 031
Venetian



DAS 006
S006



DAS 012
Hamilton



DAS 016
Gothic



DAS 033
Royal Albert



DAS 008
Grecian



DAS 013
Roman



DAS 029
Cuban



DAS 034
Royal Elizabeth



DAS 009
Colonial



DAS 014
Tuscan



DAS 030
Fresco



DAS 036
Ivory

Ceiling Tiles



DAS 021
Ross

DAS 018
Skye

DAS 020
Fife

DAS 022
Selkirk



DAS 019
Lanark

DAS 017
Perth

DAS 004
Vintage

Ceiling Roses



DAS 001
diam. 400

DAS 002
diam. 450

DAS 003
diam. 530

Please visit our website to see our Product Gallery – www.fergo.co.za

Cornicing Installation

Cut, Glue and Stick ...



Cut your corners as per the pictures above. See installation cd in our DIY KIT, or refer to our website, www.fergo.co.za



Generously apply DAS 2 in 1 Adhesive to the top and bottom edges of the cornice and to the butt joints.



Using mild pressure, place your cornice, allowing the adhesive to squeeze out. Then remove excess adhesive with a damp sponge.

Ceiling Tile Installation

Prepare, Glue and Stick ...



Prepare, clean and dry the surface. Using a tape measure, divide your ceiling into four equal parts, and mark with a chalk line. Generously apply DAS 2 in 1 Adhesive to the back of the tile.

Using mild pressure, place your tile, starting at the centre and working towards the corners. Immediately remove excess adhesive with a damp sponge. Installation cd available in DIY KIT, or refer to our website, www.fergo.co.za

Adhesives

Only use DAS 2 in 1 Adhesive



310ml Tubes

2 in 1 Adhesive Six Pack
(Six sausages and Reusable cartridge)

DIY KIT

It's never been this easy



DAS
Dynamic Artistic Solutions

