

NEW WORK/REPAINT: NEW WORK – INTERIOR / EXTERIOR

SUBSTRATE: Metals - Galvanized Iron

PAINT FINISH: Plascon Super Universal Enamel PRODUCT CODE: **NY 1/G**
(Smooth finish – solvent based, superior high gloss enamel)

COLOUR: White and standard colours as per colour card, plus Plascon colour system and other fan decks.

ENVIRONMENT: **The Maintenance Cycle is a guide but can vary due to micro-climate changes identified on the site which will affect the longevity of the coating system**

As per ISO 12944-2:1998 Maintenance Cycle (Years)

C1 -	Inland	3
C3 -	Industrial	3
C5 -	Coastal / Marine	3

Plascon Coating System	Application Method	Spreading Rate m ² /ℓ	WFT/DFT μm (min & max)	Reducer/ Cleaner	Overcoating time h @ 23 °C	Technical Data Sheet No	TVOC g/ℓ
Primer Plascon Metalcare Metal WB Primer (MWP 1)	B, R or S	@ 55 μm Theo: 6.7 Prac: 4.4	WFT 135-162 DFT 50-60	Water	WB topcoat: 8 SB topcoat: 16	MWP 1	26
1st Finishing Coat Plascon Super Universal Enamel (NY 1/G/TSE)	B, R or S	@ 30 μm Theo: 16.3 Prac: 9	WFT 51-71 DFT 25-35	Min. Turps (AZH 1)	16	NY 1/G	381 white <415 tint bases
2nd Finishing Coat Plascon Super Universal Enamel (NY 1/G/TSE)	B, R or S	@ 30 μm Theo: 16.3 Prac: 9	WFT 51-71 DFT 25-35	Min. Turps (AZH 1)	16	NY 1/G	381 white <415 tint bases

SURFACE PREPARATION:

Galvanized iron in good condition:

- ^ Apply Plascon Galvanized Iron Cleaner (GIC 1) to all bare Galvanized areas by brush, broom or spray.
- ^ Allow to react for 1 minute. Rinse off with tap water using bristle brooms or brushes or Scotch Brite pads to remove all surface contaminants.
- ^ Check if surface is water break-free. If not, repeat process. Allow to dry completely.

Old Galvanized iron partially rusted:

- ^ Apply Plascon Galvanized Iron Cleaner (GIC 1) to all bare Galvanized areas by brush, broom or spray.
 - ^ Allow to react for 1 minute. Rinse off with tap water using bristle brooms or brushes or Scotch Brite pads to remove all surface contaminants.
 - ^ Check if surface is water break-free. If not, repeat process. Allow to dry completely.
 - ^ Mechanically wire brush or hand sand rust areas to bright metal. Remove dust.
 - ^ Spot prime areas where rust has been removed with Plascon Plascotuff 3000 Series (PEX 3004 Grey/PEH 3 Hardener) Allow 16 hours to dry.
-

APPLICATION:

Primer

- ^ Apply one coat of Plascon Metalcare Metal WB Primer (MWP 1) to achieve a continuous film. Allow 8 hours to dry before overcoating with a waterbased topcoat or allow 16 hours when overcoating with a solvent based topcoat.

Finishing Coats

- ^ Apply two full coats of Plascon Super Universal Enamel (NY 1/G/TSE) to achieve complete obliteration, allowing 16 hours drying between coats.
NB: if white is used, three coats might be necessary to achieve obliteration.
-

TABLE REFERENCES:

- ^ Technical Data Sheet (TDS): User must always ensure that latest issue is used.
- ^ B = Brush (ready for use), R = Roller (synthetic, min. 10mm pile) (ready for use), S = Airless spray (ready for use).
- ^ Theoretical spreading rate quoted is for smooth non-porous substrates and does not include allowance for surface profile, porosity, wastage and uneven film application. Suitable allowance should be made according to type of work, method and skill of applicator. Practical spreading rate quoted is an average guide only - actual must be determined by user.
- ^ Overcoating times are at 23 °C and 75 % relative humidity. Longer times must be allowed under cooler and moist conditions. DO NOT paint during inclement weather and when temperature is below 10 °C.
- ^ Fading and chalking will occur to a greater or lesser degree depending on pigmentation and generic binder type.
- ^ NB: Life expectancy may vary, depending on environmental conditions and stresses, within the macro/micro climate of the project.

Copyright ©Kansai Plascon (Pty) Ltd 2013. All rights reserved. No part of this work may in any form or by any means be reproduced without prior written permission of the copyright owner. PLASCON is the registered trade mark of Kansai Plascon (Pty) Ltd,
