

# SPECIFICATION SHEET NO: NW443

NEW WORK/REPAIN	NT: NEW WO	NEW WORK – EXTERIOR Metals – Galvanised Iron						
SUBSTRATE:	Metals –							
PAINT FINISH:	(Smooth aluminiur		based, bituminous cellent waterproofing		PRODUCT CODE: <b>RMB 1</b>			
COLOUR:	Silver							
ENVIRONMENT:		itenance Cycle is vhich will affect t	-	-		hanges identifie	ed on	
	As per ISC	As per ISO 12944: Maintenance Cycl			(Years)			
		Inland		4				
		Industrial Coastal / Marine		3 3				
Plascon Coating System	Application Method	Spreading Rate m <sup>2</sup> /e	WFT/DFT μm (min & max)	Reducer/ Cleaner	Overcoating time h @ 23 °C	Technical Data Sheet No	TVOC g/୧	
Primer Plascon Plascosafe 18 Primer (EMS 18)	B, R or S	@ 55 μm Theo: 6.7 Prac: 4.4	WFT 135- 162 DFT 50-60	Water	WB topcoat: 8 SB topcoat: 16	EMS 18	53.5	
1 <sup>st</sup> Finishing Coat Plascon Bituminous Aluminium Paint (RMB 1)	B, R or S	@ 27.5 μm Theo: 13 Prac: 7.1	WFT 56-97 DFT 20-35	Min Turps (AZH 1)	16	RMB 1	590	
2 <sup>nd</sup> Finishing Coat Plascon Bituminous Aluminium Paint (RMB 1)	B, R or S	@ 27.5 μm Theo: 13 Prac: 7.1	WFT 56-97 DFT 20-35	Min Turps (AZH 1)	16	RMB 1	590	





### SPECIFICATION SHEET NO: NW443

### SURFACE PREPARATION:

### Galvanised iron in good condition:

Apply Plascon Galvanised Iron Cleaner (GIC 1) to all bare Galvanised areas by brush, broom or spray. Allow to react for 1 minute. Rinse off with tap water using bristle brooms or brushes or Scotch Brite pads to remove all surface contaminants. Check if surface is water break-free. If not, repeat process. Allow to dry completely.

## Old Galvanised iron partially rusted:

Apply Plascon Galvanised Iron Cleaner (GIC 1) to all bare Galvanised areas by brush, broom or spray. Allow to react for 1 minute. Rinse off with tap water using bristle brooms or brushes or Scotch Brite pads to remove all surface contaminants. Check if surface is water break-free. If not, repeat process. Allow to dry completely. Then mechanically wire brush or hand sand rust areas to bright metal. Remove dust. Spot prime areas where rust has been removed with Plascon Plascotuff 3000 Series (PEX 3004 Grey/PEH 3 Hardener). Allow 16 hour to dry.

### **APPLICATION:**

### **Primer Coat**

Prime the entire surface with Plascon Plascosafe 18 Primer (EMS 18) to achieve a continuous film. Allow 8 hours drying time (water based topcoat) or 16 hours drying time (solvent based topcoat).

### **Finishing Coats**

 Apply two full coats of Plascon Bituminous Aluminium Paint (RMB 1) to achieve complete obliteration, allowing 16 hours drying between coats.

#### **TABLE REFERENCES:**

- Technical Data Sheet (TDS): User must always ensure that latest issue is used.
- A B = Brush (ready for use), R = Roller (synthetic, min. 10mm pile) (ready for use), S = Airless spray (ready for use).
- ^ Theoretical spreading rate quoted is for smooth non-porous substrates and does not include allowance for surface profile, porosity, wastage and uneven film application. Suitable allowance should be made according to type of work, method and skill of applicator. Practical spreading rate quoted is an average guide only - actual must be determined by user.
- Overcoating times are at 23 °C and 75 % relative humidity. Longer times must be allowed under cooler and moist conditions. DO NOT paint during inclement weather and when temperature is below 10 °C.
- A Fading and chalking will occur to a greater or lesser degree depending on pigmentation and generic binder type.
- NB: Life expectancy may vary, depending on environmental conditions and stresses, within the macro/micro climate of the project.

Copyright @Kansai Plascon (Pty) Ltd 2013. All rights reserved. No part of this work may in any form or by any means be reproduced without prior written permission of the copyright owner. PLASCON is the registered trade mark of Kansai Plascon (Pty) Ltd,

