



CLOSE COUPLED -DIRECT SYSTEM



system comprises of a 110lt solar water heater, self-filler tank, 12 vacuum tubes and stand



Solar Water Heaters - Close Coupled - Direct System

close coupled - direct system

The direct system is used where the water quality is good (less than 600ppm Total Dissolved Solids/Minerals).

A direct system is where the water to be used in the household (hot water) is heated by means of solar radiation absorption by the vacuum tubes and directly heats the water in the solar water heater.

In the close coupled system the vacuum tubes are an intergral part of the storage tank and the heated water in the tubes rises and heats the water in the tank, known as a thermosyphon system. The system operates according to the basic principles of physics.

product features of the complete low pressure system

The Complete Low Pressure System is ideal for low cost housing, where homes do not have an electric water heater to supply hot water. and in rural areas and homes where electricity is not readily available to heat water. It provides hot water to those who do not have the luxury of having hot water on tap.





- . The horizontal solar water operates at zero pressure and relies on gravity to feed water to the taps
- The self filler tank controls the water flow into the solar water heater. The self-filler tank has a high pressure float ball valve, which allows for a direct connection to the municipal mains supply, without any additional valves.
- The solar water heater relies solely on solar radiation transmitted via an array of vacuum tubes to heat the water and does not have an electrical element and thermostat as a back-up.

Capacity (Litres)	Operating Pressure (kPa)	Mass Empty (kg)	Filler Tank Water Inlet Connection & Air Vent (BSP Male)		Overflow Connection on End Dome (BSP Female)		Diameter (mm)
110	0	30	1/2"	3/4"	3/4"	1180	470



Solar Vacuum Tubes

solar vacuum tubes features


- Vacuum tubes consist of two glass tubes manufactured from borosilicate glass.
- The outer glass is transparent allowing light rays to pass through with minimum reflection.
- The inner glass is coated with a special solar selective coating (Al-N/A1), which provides excellent solar radiation absorption.
- The tops of the tubes are fused together and the air is extracted, which forms a vacuum, which is key to the efficiency of the vacuum tubes.
- If the vacuum is ever lost, the silver inner coating will turn white.
- The water is directly heated in the vacuum tubes.
- Tubes are freeze and hail resistant.

solar vacuum tubes specification data

Tube Dimension (mm)	Assembled Dimensions 12 Tubes (mm)	Absorption Area (m²)	Mass Empty (kg)
1800 (I) x 58 (diameter)	1700 (l) x 1050 (w) x 1070 (h)	1.2	18


assembly stand

A floor stand is available for flat roofs and this same stand can be cut down to size and used for a pitched roof installation on roof pitches of more than 8° and less than 30°.



installation location data

- For optimum performance complete assembled system needs to face the equator and facing north for southern hemisphere installations. Installations on angles of up to 45° away from the equator do not have a major effect on the annual solar output, consequently roof locations, which face less that 45° away from the equator are acceptable. Solar radiance from the sun occurs at about 10:00 until about 16:00 and at its peak between 12:00 and 14:00.
- If the solar vacuum tubes are installed with an east facing bias, the best solar capture is in the morning and if installed with a west facing bias, in the afternoon.
- The location should not be subjected to excessive shading from trees and other buildings and particularly between 9:00 and 15:00. Shadows are longer in winter so a location that is free of shadows in summer may have some shadows in winter.





Solar Water Heaters - Close Coupled - Direct System

product warranty

The warranty period on the Kwikot Low Pressure Solar Water Heater is from date of installation providing that documented proof of installation is furnished, or alternatively from date of manufacture as determined from the serial plate code on the solar water heater.

- One year on the self-filler tank and float ball valve.
- Five years on the inner cylinder (tank), subject to water conditions equivalent to main Metropolitan supply authorities.
- · The warranty on the installation is the responsibility of the installer.

The solar vacuum tubes have a comprehensive 5 year warranty from date of installation and subject to the following conditions:

- The warranty only applies to defects, which have arisen solely due to faulty materials and workmanship during the manufacturing process of the vacuum tubes.
- If any component fails during the warranty period, Kwikot will replace or repair the failed component free of charge.
- Breakage or cracks to the vacuum tubes is not covered by the warranty.
- · The warranty on the installation is the responsibility of the installer.

product codes

Product Code SOL-110-LP (Complete System) Low Pressure Solar Water Heater with Self-Filler Tank, Array of 12 Vacuum Tubes and Floor Stand

KWIKOT (PTY) LTD INLAND DIVISION

PO BOX 1016 BENONI, 1500, TEL: (011) 897 4600 FAX: (011) 914 4750

AFTER SALES SERVICE TEL: 0861 KWIKOT (594568) DOMESTIC SALES e-mail:sales.inland@kwikot.com

DOMESTIC SALES
e-mail:sales.inland@kwikot.com
EXPORT SALES
e-mail:sales.export@kwikot.com
MARKETING
e-mail:marketing.info@kwikot.com
TECHNICAL
e-mail:solar.info@kwikot.com

KWIKOT (PTY) LTD EASTERN CAPE DIVISION

PO BOX 3082, NORTH END PORT ELIZABETH, 6056. TEL: (041) 373 0575 FAX: (041) 373 0577

DOMESTIC SALES e-mail; sales.easterncape@kwikot.com

KWIKOT (PTY) LTD WESTERN CAPE DIVISION

PO BOX 443, EPPINDUST, 7475. TEL: (021) 534 3691 FAX: (021) 534 1606

DOMESTIC SALES e-mail: sales.westerncape@kwikot.com

KWIKOT (PTY) LTD KWAZULU-NATAL DIVISION PO BOX 47366

PO BOX 47366 GREYVILLE, 4023. TEL: (031) 574 8700 FAX: (031) 574 8750

DOMESTIC SALES e-mail; sales.kwazulunatal@kwikot.com

02/2011 SOL LP 110L